

Water Filter Setup

Subject: Water Filter Setup

Date: January 14, 2026

Models / Parts Affected: TCIM

Voltages: All Voltages


Overview

This document describes how to set the water filter capacity on TCIM models to ensure the water filter replacement reminder alerts correctly for your application.


Procedure

Select Water Filter Capacity

1. Power the TCIM.
2. Press the menu gear icon.



3. In the menu screen, select the water filter menu.




4. In the filter selection screen, select the appropriate water filter for your application. If none of the preset options match your application, select **CUSTOM**. See filter capabilities in the table below.



Filter Type	Capacity
Standard	14,000 gal (52,996 L)
Platinum	35,000 gal (132,490 L)
Custom* (default)	10,000 gal (37,854 L; adjustable)

*If using a non-TRUE water filter, enter the water capacity under **CUSTOM**.

5. If applicable, in the custom screen, enter the water filter capacity that matches your water filter's rating. Press okay .






Water Filter Setup

Procedure (cont.)

Select Water Filter Capacity (cont.)

6. Return to the home screen, press the back icon twice (2x).



Technical Questions or Concerns

For more information, please contact our Technical Support team.

Warranty Phone: +1 855-299-3510
Warranty Email: WarrantyInquiries@TrueMfg.com
Technical Phone: +1 888-783-1429
Technical Email: CommercialIce@TrueMfg.com